

## SM-001 (D-4101) FFP2 Safety Mask

- Inner : Non-Woven Fabric (PP)
- Outer : Non-Woven Fabric (PP)
- Filter: Melted Blown Fabric (BFE≥95%)
- Shape : Cup Design Mask With or Without Valve
- Color Available: White
- Package: 10PCS/Box, 400PCS/Carton (61x42x29CM)
- CE EN149-2001 FFP2 NR
- Application : Construction, Road & Building Workers, Woodworking, Mining, Casting, Grinding, Food & Cleaning Industry, Electronics, Most Dust Generated Workplaces etc



### Users Instruction:

#### 1.) FITTING INSTRUCTIONS :

- Hold the mask in hand with the metal nose piece up. Allow head harness to hang freely.
- Position the mask under the chin, covering mouth and nose.
- Pull the lower head harness over the head, position below ears. Full the top head harness on the back of head above ears for best fit.
- Press soft metal nose piece fit snugly around the nose.
- Check the seal and repeat procedure until the mask is sealed properly.

#### 2.) THE USER SHOULD ENSURE:

- Please check the production date and expiry date before use. Make sure the mask are within expiry date.
- Don't use the mask if environmental pollutants are seriously endanger, or the oxygen concentration is below 18%.
- Thelf you feel dyspnea, dizziness, nausea or uncomfortable, please go to a safe place and rest yourself immediately.

#### 3.) LIFESPAN

The Mask can be expected to remain in service for 3 years or more, when it is in well stored condition.

#### 4.) DISPOSABLE USE

The Mask is only for disposable use. Please don't use it repeatedly or use it by multiple people. When the mask is damaged or the respiratory resistance increase, please replace a new mask immediately.

#### 5.) STORAGE

The Mask must be stored in a ventilated and dry place. Keep it away from flammable and explosive materials. Recommended storage temperature is -20°C to 30°C, Recommended humidity is < 80%.